Redcord DoorFix

REF 111603

Instructions for use / EN



Redcord AS
Teknologiveien 11
NO-4846 Arendal, Norway

CE

The Redcord DoorFix is an accessory to the Redcord Mini (REF 110020-2). It is used to mount the Redcord Mini to a door.

⚠ **CAUTION:** Use only sturdy doors that can be securely closed. Do not use sliding, hollow, or lightweight doors.

WARNINGS AND PRECAUTIONS:

- Before starting the exercises:
  - Check the DoorFix for damage or wear.
  - Make sure that the material has no defects.
  - Ensure that the door is sturdy, securely closed, and able to support the intended load.
  - Do not use sliding, hollow, or lightweight doors.
  - Perform a safety check by pulling both ropes forward to confirm the door is fully closed and stable.
  - Make sure Redcord Mini has been attached correctly to the DoorFix by performing a safety check.
- Respect the maximum load limit: 200 kg (100 kg per rope).
- Never let children play with or use the Redcord products unsupervised.
- Do not use glass doors or loose frames. Do not use DoorFix where blocking the door creates a hazard (e.g., fire exits).
- Do not repair or sew damaged straps/webbing.
- **Withdraw**: recommended lifetime is 4 years. Stop using DoorFix immediately and replace it if any part shows signs of wear, cracks, deformation, damaged stitching/webbing, or other visible defects. Do not use the product if it has been modified, exposed to chemicals or harsh conditions, or if there is any doubt about its safety.

⚠ CAUTION: Frequent exposure to direct sunlight, temperature variations, or high humidity while in use or storage can cause the device to wear out sooner than expected, leading to potential slipping or breakage during use. Prolonged storage can also reduce the device's overall lifespan, causing it to wear out faster and potentially break during use.

PROPER USE

- Place the DoorFix over the top edge of a solid, securely closing door so that both ends hang on each side of the door.
- Ensure the “STOP – DO NOT OPEN” sign is clearly visible.
- Close the door securely to lock the DoorFix between the door and the frame, ensure the latch is engaged.
- Attach the Redcord Mini by threading the rope through the ring on the DoorFix, then through the rope lock on the Mini. Pulling both ropes forward to test the sturdiness and confirming the door is closed.



NOTE: The exercise should always be performed on the side where the door opens away from you, not towards you.

STORAGE

- Store DoorFix in a dry, cool place with good air circulation.
- Avoid direct sunlight, extreme temperatures, humidity, and chemical exposure.
- Do not dry in a dryer or under sunlight.
- Prolonged exposure to harsh conditions may reduce product durability and lifespan.

- **Disposal:** The device does not contain hazardous substances. Components made of plastic, metal, and textile can be disposed of or recycled according to local regulations.

CLEANING AND DISINFECTION

Not intended to be sterilized.

Before use and between uses: inspect the external surfaces for damage or wear. Clean the contact surfaces. If required by local hygiene procedures, disinfect them. Use only a non-bleach, non-corrosive disinfectant compatible with textiles.

The DoorFix can be hand washed or with a soft brush with lukewarm soapy water.

Drying: Air dry only. Avoid direct sunlight, drying cabinets, or heat sources (e.g., radiators).

After cleaning: Ensure the product is completely dry before storage/use; do not wring/twist.

WARRANTY

2 years. The warranty covers any faults in materials or manufacture. The warranty period runs without interruption for a period of 24 months from the delivery date of the products from Redcord AS. Exclusions from the guarantee: normal wear and tear, modifications or alterations, incorrect storage, poor maintenance, negligence, improper or incorrect usage. The warranty is valid only if there are deficiencies in the product, i.e., it is clearly wrong according to technical specifications and how the product is intended to be. Incorrect use and normal wear and tear are not eligible for a claim. Redcord‘s obligations pursuant to this warranty are limited to repair or replacement.

Redcord AS does not take any responsibility for personal injury or physical damage due to the condition of the door/door frame used during physical activities.

Any serious incident that has occurred in relation to the device should be reported to the **manufacturer** and to the competent **authority of the Member State** in which the user or patient is located, in accordance with applicable national requirements. For contact details, see the end of this instruction for use.

Explanation of symbols and abbreviations

	Symbol Glossary
CE	Conformity with applicable EU legislation (MDR 2017/745).
REF	Catalogue number (REF)
UDI	Unique device identifier (UDI) The product label includes a UDI for traceability.
	Manufacturer
LOT	Batch code
	Caution
	Keep dry
	Keep away from sunlight
	Consult Instructions for use

Contact and technical support
Redcord AS,
Teknologiveien 11, NO-4846 Arendal, Norway
redcord@redcord.com +47 37 03 00 00
Local Distributors: www.redcord.com